


Installation steps:

- 1, Fill liquid soap into bottle capacity.
- 2, Press and hold the dispense button on the control box, release till the soap is dispensed.
- 3, Start the system by passing your hand in the sensor range, soap will dispense automatically.

Note: It has four soap dispense volume adjustment:

- 1: Low volume
- 2, Normal volume
- 3, Medium volume
- 4, High volume




Caution:

- 1, Ensure soap is free of particles, and filling cup is clean.
- 2, Clean soap tank with water periodically.
- 3, Refill soap when soap level is approximately 20mm.
- 4, Replace batteries when red light in sensor window blinks.
- 5, Use soft and moist cloth to clean, avoid spraying water directly at the system.

Automatic soap dispenser


Instruction



Specifications:

Model No.	RB.TRC.0BA100.CB.PB
Material	Brass
Sensing range	15±3cm
Activation time	0.5-1s
Power supply	AC:220V DC:1.5V 4pcs
Viscosity	100-3500cp (mpA • s)
Soap volume	≤2mL/times(four gear)
Bottle capacity	1.6-2L
Ambient temp.	Normal temperature

Installation:



Roughing in:

